

Bear Wood Furniture

Montessori Toy Shelf



Assembly Instructions

Please ensure you've read our 'Safety & Usage' document before you begin.

Please use the square pocket hole drill bit provided with an adjustable screwdriver. We advise you do not use power tools as they can over tighten the screws and damage the wood.

1. Open and lay out contents of package (Picture 1).
2. Start by choosing one of the side pieces and lay it on a clean flat surface with the pencil side up. (The pieces with a rounded corner) (Picture 2).
3. Starting with piece 1, screw in the two pocket hole screws into the side piece, making sure the back of the piece lines up with the pencil markings, and the bottom of the side and piece 1 are flush (Picture 3).
4. Repeat for pieces 2, 3 4 and 5 (Picture 4).

Please note, as our pieces are handmade, they can vary by a couple of mm, we recommend ensuring the front of the shelves are flush with the front edge of the side pieces, hiding variations in width at the back which won't be visible.

All pencil markings can be sanded off (use the coarser brown paper first, finish with the finer yellow paper). LBT = Left Back Top // RBT = Right Back Top.

5. Once all pieces have been screwed into the side piece, place the 2nd side piece pencil side up, symmetrically to the first side (match the round corner) (Picture 5).
6. Carefully flip the partially assembled toy shelf onto the 2nd side piece (Picture 5).
(Safety note -we recommend grabbing a friend to help you, although it can be done individually).
7. Start screwing the pieces into the 2nd side piece, ensuring all numbers are matched, and lines are adhered to. Please screw the middle pocket hole screws last (circled in picture) (Picture 6 & 7).
8. Attach the angle brackets to the toy shelf in a convenient place, using the small silver screws provided, and then secure the toy shelf to a wall or skirting board using the larger gold screws (Pictures 8 & 9).

- We recommend attaching the bracket to the underside of a shelf, allowing you to screw into a wall (See advisory photos on next page).

Please refer to our 'Usage & Safety' document for additional guidance. We hope you enjoy your new bookshelf!

Contact us @bearwoodfurniture_ // george@bearwoodfurniture.com

Bracket Advice;

Use the smaller silver 16mm screws to attach the bracket into the furniture piece, pushing the bracket flush to the wall or skirting board.



Once the bracket is secured to the furniture piece, use the longer 30mm woodscrews to secure through the bracket and into the wall stud or skirting board

(16mm screws)

Test the furniture piece to ensure it can't topple or moved if pushed, knocked or climbed whilst in use.



(30mm screws)



Picture 1 ^



Picture 2 ^



Picture 3 ^



Picture 4 ^



Picture 5 ^



Picture 6



Picture 7



Picture 8



Picture 9

